



These instructions apply to all models shown below.








IMPORTANT NOTE:


- ullet Place all wooden parts on a clean, smooth surface to prevent the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children.

PAGE 1 OF 6













Attach the two End Base (C) and Center Base (E) to Modesty Panel (B) by using Cam Lock (C1) and Klix Cam (C2).



Attach the Flat-Bracket (A2) to two Top Panel (A) as shown. Tighten Screws (A3) securely.










PAGE 3 OF 6








Lock (D1/F1) and Klix Cam (D2/F2).







PAGE 4 OF 6




ASSEMBLING TABLE WITH V-LEG BASE



Attach Cube Base (G) by using Cam Lock (G1) and Klix Cam (G2).




3



Attach Cube Base Support (G) by using Cam Lock (G1) and Klix Cam (G2).

4


Attach the Flat-Bracket (A5) to two Top Panel (A) as shown. Tighten Screws (A6) securely.



Join the two Top Panels (A) by using KD Fitting (A1) and Klix Cam (A2).

Attach the Fitting-GL Screw (A7) to two Top Panel (A) as shown by using Wrench (A8).


5 Attach Top Panel (A) to Cube Base (G) by using JCBC Screw (G4) and tighten with Allen Key (G6).




PAGE 5 OF 6




ASSEMBLING TABLE WITH V-LEG BASE





ASSEMBLING TABLE WITH V-LEG BASE + SQUARE POST LEG



PAGE 6 OF 6