


Before assembly, please remove all parts from the carton, verifying that you have the correct quantities, and read all the instructions.

IN THE CARTON + INSTRUCTIONS:



A: Backrest ≈ 1 PC

B: Seat ≈ 1 PC

C: Frame ≈ 2 PCS

 D₁: 1/4 X 7/8 = 6 PCS

 D₂: 1/4 X 7/8 = 6 PCS

 E: 4mm ≈ 1 PC

⚠ ATTENTION ⚠

Do not tighten any screws or bolts until the unit is completely assembled.

Ensure all bolts and screws are tightened before using the chair. Check bolts and screws every 6 months.

If any parts are missing, broken, damaged or worn, stop use of product until repairs have been made using factory authorized parts. Failure to follow these warnings may result in injury.