




PL 131ATMGG, PL147ATMGG BULLET TABLE


Thank you for purchasing the Performance Bullet Table. Please follow these instructions for easy assembly.





KLIX CAM INSTRUCTIONS






IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children.

PL 131ATMGG, PL147ATMGG BULLET TABLE



Attach the Side Center Panel (C) to Side Panel (B) by using Cam Lock (1) and Klix Cam (2).

2

Attach the L-Bracket (5) to Top Panel (A), Side Panel (B) and Side Center Panel (C) as shown. Tighten Screws (6) securely.

Attach the Side Center Panel (C) and Side Panel (B) to Top Panel(A) by using Cam Lock (1) and Klix Cam (2).

