




Thank you for purchasing the Performance Porkchop Bullet. Please follow these instructions for easy assembly.



## KLIX CAM INSTRUCTIONS






## **IMPORTANT NOTE:**

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children.







Attach the Center Panel (D) and End

Panel (C) to Side Panel (B) by using

Cam Lock (1) and Klix Cam (3).

