
3

KLIX CAM INSTRUCTIONS

MODEL: PL137THALF + PL237THALF & PL139

1/2 RACETRACK / BOAT SHAPE TOP (REQUIRES BASE)



IMPORTANT NOTE:

WITH V-LEG/U-LEG BASE

WITH V-LEG/SQUARE

POST LEG BASE

See Page 7

See Page 7

• Place all wooden parts on a clean, smooth surface to prevent the parts from being scratched.

WITH V-LEG/U-LEG BASE

WITH V-LEG/SQUARE

POST LEG BASE

- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children.


See Page 7

See Page 7

MODEL: PL137THALF + PL237THALF

1/2 RACETRACK / BOAT SHAPE TOP (REQUIRES BASE)


COMPONENTS:





MODEL: PL139


RACETRACK / BOAT SHAPE CONFERENCE TABLES (REQUIRES BASE)





MODEL: PL137THALF + PL237THALF


1/2 RACETRACK / BOAT SHAPE TOP (REQUIRES BASE)


ASSEMBLING TABLE WITH END PANEL BASE














MODEL: PL137THALF + PL237THALF


1/2 RACETRACK / BOAT SHAPE TOP (REQUIRES BASE)

ASSEMBLING TABLE WITH ELLIPTICAL BASE












MODEL: PL137THALF + PL237THALF

1/2 RACETRACK / BOAT SHAPE TOP (REQUIRES BASE)

ASSEMBLING TABLE WITH ELLIPTICAL BASE









MODEL: PL137THALF + PL237THALF


1/2 RACETRACK / BOAT SHAPE TOP (REQUIRES BASE)

ASSEMBLING TABLE WITH V-LEG BASE






ASSEMBLING TABLE WITH V-LEG BASE + SQUARE POST LEG




MODEL: PL139

RACETRACK / BOAT SHAPE CONFERENCE TABLES (REQUIRES BASE)



Attach Center Base (F) to Modesty Panel (B)


by using Cam Lock (E1/F1) and Klix Cam (E2/F2). Attach Modesty Panel (C) to Center Base (F) by using Cam Lock (E1/F1) and Klix Cam (E2/F2). Attach End Base (E) to Modesty Panel (C) by using Cam Lock (E1/F1) and Klix Cam (E2/F2). Attach Top Panel (A) & Top Panel (D) to Center Base (F) & End Base (E) & Modesty Panel (B/C) by using Cam Lock (E1/F1) and Klix Cam (E2/F2).



MODEL: PL139


RACETRACK / BOAT SHAPE CONFERENCE TABLES (REQUIRES BASE)

OPTION 2



Attach the Flat-Bracket (A5/D5) to two Top Panel (D) and Top Panel (A) as shown. Tighten Screws (A6/D6) securely.

Attach Center Eleptical Base (J) to Modesty Panel (G) by using Cam Lock (J1/I1) and Klix Cam (J2/I2) Attach Modesty Panel (H) to Center Base (I) by using Cam Lock (J1/I1) and Klix Cam (J2/I2). Attach Eleptical Base (J) to Modesty Panel (H) by using Cam Lock (J1/I1) and Klix Cam (J2/I2). Attach Top Panel (A) & Top Panel (D) to Center Eleptical Base (I) & End Base (J) & Modesty Panel (G/H) by using Screw (J7/I8).



from Top Panel (A/D) to Modesty Panel (G/H) and Eleptical Base (I) and Center Eleptical base (J) as shown. Tighten Screws (A6/D6/J7/I8) securely.

> Attach Top Panel (A) & Top Panel (D) to Center Eleptical Base (I) & End Eleptical Base (J) & Modesty Panel (G/H) by using Screw (J7/I8).



MODEL: PL139

RACETRACK / BOAT SHAPE CONFERENCE TABLES (REQUIRES BASE)

