

ASSEMBLY INSTRUCTIONS

MODEL: PL40+PL41+PL44(SGD+BGD)



2PCS PER SET (FOR: PL140OH+PL141OH+PL144OH)



PERFORMANCE
FURNISHINGS


Before assembly, please remove all parts from the carton, verifying that you have the correct quantities, and read all the instructions.

IN THE CARTON:




INSTRUCTIONS:

OPTION 1




Tighten Door Hinges (2) with Screw (3). Hinges are adjustable, to help them line up.



OPTION 1


Attach the Doors Panel (B) to the Side Panel of HUTCH (A) with Hinges (2) and Screw (3)

OPTION 2




Tighten Door Hinges (2) with Screw (3).

Attach the Doors Panel (B) x 2 SETS to the Center Vertical Panel and Side Panel of OPEN HUTCH (A) with Hinges (2) and Screw (3)



Stick the Door Stopper (1) on the Fixed Shelf of HUTCH(A)



OPTION 2

⚠ ATTENTION ⚠

Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.

Check that you have all parts and hardware.

Remove all wrapping materials, including staples & packing straps before you start to assemble.

Do not tighten any screws or bolts until the unit is completely assembled.

Keep all hardware parts out of reach of children. There may be extra hardware when install is complete.